

# **7890IXG**

## **Internet Exchange Gateway**

### **User Manual**

© Copyright 2017

#### **EVERTZ MICROSYSTEMS LTD.**

5292 John Lucas Drive  
Burlington, Ontario  
Canada L7L 5Z9

Phone: +1 905-335-3700  
Sales: [sales@evertz.com](mailto:sales@evertz.com) Fax: +1 905-335-3573  
Tech Support: [service@evertz.com](mailto:service@evertz.com) Fax: +1 905-335-7571  
Web Page: [www.evertz.com](http://www.evertz.com) Twitter:  [@evertzTV](https://twitter.com/evertzTV)

Version 2.3, April 2017

The material contained in this manual consists of information that is the property of Evertz Microsystems and is intended solely for the use of purchasers of 7890IXG series products. Evertz Microsystems expressly prohibits the use of this manual for any purpose other than the operation of the device.

All rights reserved. No part of this publication may be reproduced without the express written permission of Evertz Microsystems Ltd. Copies of this manual can be ordered from your Evertz dealer or from Evertz Microsystems.

*This page left intentionally blank*

## TABLE OF CONTENTS

1. INTRODUCTION .....	1
2. GETTING STARTED .....	3
3. SPECIFICATIONS .....	5
4. SETUP GUIDE.....	7
4.1. INITIAL SETUP USING SERIAL PORT OR USB PORT .....	7
4.2. LICENSING.....	9
4.2.1. Upgrading License Using Webeasy .....	9
4.2.2. Upgrading License Using VLPro .....	10
4.3. SETUP COMMUNICATION BETWEEN TX SIDE AND RX SIDE .....	11
4.3.1. Side 1 (TX) .....	11
4.3.2. Side 2 (RX) .....	17
4.4. TROUBLESHOOTING .....	20
4.4.1. No Signal communication between TX side and source:.....	20
4.4.2. No Signal communication between RX side and Destination: .....	21
4.4.3. TX Side Not Streaming with RX Side or Stream Not Received by RX Side .....	22
4.4.4. Data Loss on RX Side:.....	23
4.4.5. VLPro not detecting the card.....	24
4.4.6. Web page not responding.....	27
5. WEBEASY REFERENCE CONTROLS .....	29
5.1. SYSTEM .....	29
5.1.1. Information.....	29
5.1.2. License Control.....	29
5.1.3. Configuration Management.....	29
5.1.4. Control.....	30
5.2. IP INPUT.....	30
5.2.1. Access Port Control .....	30
5.2.2. Access Port Monitor.....	30
5.3. INTERNET .....	31
5.3.1. Internet Port Control .....	31
5.3.2. Internet Port Monitor .....	32
5.3.3. Buffer Control .....	32
5.4. INTERNET INPUT IP STREAM .....	33
5.4.1. Stream Control.....	34
5.4.2. Network .....	34
5.4.3. ARQ.....	34
5.4.4. Monitoring.....	35
5.4.5. Network Status .....	35

5.4.6. ARQ Status.....	35
<b>5.5. INTERNET OUTPUT IP STREAM .....</b>	<b>36</b>
5.5.1. Stream Control .....	36
5.5.2. Stream Status.....	37
5.5.3. Receive Status .....	37
5.5.4. Transmit Status .....	37
<b>5.6. SERVER .....</b>	<b>37</b>
5.6.1. Server.....	37
<b>5.7. NOTIFY.....</b>	<b>38</b>
5.7.1. Output Notify.....	38
5.7.2. Input Notify .....	38
<b>5.8. TRAPS.....</b>	<b>38</b>
<b>5.9. TOP MENU BAR .....</b>	<b>39</b>
5.9.1. Refresh.....	39
5.9.2. Apply .....	39
5.9.3. Dynamic Apply.....	39
5.9.4. Upgrade.....	39
<b>6. VLPRO REFERENCE CONTROLS.....</b>	<b>43</b>
<b>6.1. SYSTEM .....</b>	<b>43</b>
6.1.1. Information .....	43
6.1.2. License Control.....	43
6.1.3. Configuration Management.....	44
6.1.4. Control.....	44
<b>6.2. IP INPUT.....</b>	<b>44</b>
6.2.1. Access Port Control.....	44
6.2.2. Access Port Monitor.....	45
Clear Stats: This control allows the user to clear all stats.	45
<b>6.3. INTERNET .....</b>	<b>45</b>
6.3.1. Internet Port Control .....	46
6.3.2. Internet Port Monitor .....	46
6.3.3. Buffer Control .....	46
<b>6.4. INTERNET INPUT IP STREAM .....</b>	<b>47</b>
6.4.1. Stream Control .....	47
6.4.2. Network .....	47
6.4.3. Monitoring.....	49
6.4.4. Network Status .....	49
6.4.5. ARQ Status.....	49
<b>6.5. INTERNET OUTPUT IP STREAM .....</b>	<b>50</b>
6.5.1. Stream Control .....	50
6.5.2. Stream Status.....	51
6.5.3. Receive Status .....	51
Port: This parameter returns the IP Stream Receive port number.	51

6.5.4. Transmit Status.....	51
<b>6.6. SERVER .....</b>	<b>51</b>
6.6.1. Server.....	51
<b>6.7. NOTIFY.....</b>	<b>52</b>
6.7.1. Output Notify.....	52
6.7.2. Input Notify .....	52
<b>6.8. TRAPS.....</b>	<b>52</b>
<b>6.9. TOP MENU BAR.....</b>	<b>53</b>
6.9.1. Refresh.....	53
6.9.2. Auto Refresh.....	53
6.9.3. Apply .....	53
6.9.4. Dynamic Apply.....	53
<b>6.10. UPGRADE .....</b>	<b>54</b>
<b>7. CARD EDGE .....</b>	<b>57</b>
<b>7.1. MODULE STATUS LEDS .....</b>	<b>57</b>
<b>7.2. SERIAL PORT .....</b>	<b>57</b>
<b>7.3. USB PORT.....</b>	<b>57</b>
<b>8. FEC .....</b>	<b>59</b>

## Figures

Figure 1-1 : 7890IXG Network Management.....	1
Figure 1-2 : Block Diagram (Typical Configuration) .....	2
Figure 2-1 : 7890IXG Rear Panel .....	3
Figure 4-1 : Tera Term Login.....	7
Figure 4-2 : Menu Screen.....	8
Figure 4-3 : Network Setup.....	8
Figure 4-4 : WebEASY <sup>®</sup> - System Tab\License Upgrade.....	9
Figure 4-5 : WebEASY <sup>®</sup> - License Upload .....	10
Figure 4-6 : VistaLINK <sup>®</sup> - System Tab\License Upgrade.....	11
Figure 4-7 : WebEASY <sup>®</sup> - IP Input Tab.....	12
Figure 4-8 : WebEASY <sup>®</sup> - TX Side .....	13
Figure 4-9 : WebEASY <sup>®</sup> - RX Side .....	14
Figure 4-10 : WebEASY <sup>®</sup> - TX Side .....	15
Figure 4-11 : WebEASY <sup>®</sup> - RX Side .....	16
Figure 4-12 : WebEASY <sup>®</sup> - IP Input.....	17
Figure 4-13 : WebEASY <sup>®</sup> - TX SIDE .....	18
Figure 4-14 : WebEASY <sup>®</sup> - RX SIDE .....	18
Figure 4-15 : WebEASY <sup>®</sup> - RX Side .....	19
Figure 4-16 : WebEASY <sup>®</sup> - TX Side .....	19
Figure 4-17 : WebEASY <sup>®</sup> - IP Input.....	20
Figure 4-18 : WebEASY <sup>®</sup> - IP Input.....	21
Figure 4-19 : WebEASY <sup>®</sup> - Internet Output IP Stream .....	22
Figure 4-20 : WebEASY <sup>®</sup> - Internet Input IP Stream .....	23
Figure 4-21 : WebEASY <sup>®</sup> - Internet Input IP Stream .....	24
Figure 4-22 : VistaLINK <sup>®</sup> - VLPro version.....	25

Figure 4-23 : VistaLINK® - Hardware .....	26
Figure 4-24 : VistaLINK® - Jar Version.....	26
Figure 4-25 : VistaLINK® - Select Jar .....	27
Figure 5-1 : WebEASY® - System Page.....	29
Figure 5-2 : WebEASY® - IP Input.....	30
Figure 4-28 : WebEASY® - Internet.....	31
Figure 4-29 : WebEASY® - Internet Input IP Stream.....	33
Figure 4-30 : WebEASY® - Internet Output IP Stream.....	36
Figure 4-31 : WebEASY® - Server .....	37
Figure 4-32 : WebEASY® - Notify.....	38
Figure 4-33 : WebEASY® - Top menu bar\Refresh .....	39
Figure 4-34 : WebEASY® - Top menu bar\Apply .....	39
Figure 4-35 : WebEASY® - Top menu bar\Dynamic Apply .....	39
Figure 4-36 : WebEASY® - Top menu bar\Upgrade.....	39
Figure 4-37 : WebEASY® - Firmware Upgrade .....	40
Figure 4-38 : WebEASY® - Browse Firmware Files .....	40
Figure 4-39 : WebEASY® - Upgrade .....	41
Figure 6-1 : VistaLINK® - VLPro System Page.....	43
Figure 6-2 : VistaLINK® - IP Input.....	44
Figure 6-3 : VistaLINK® - Internet.....	45
Figure 6-4 : VistaLINK® - Internet Input IP Stream.....	47
Figure 6-5 : VistaLINK® - Internet Output IP Stream.....	50
Figure 6-6 : VistaLINK® - Server .....	51
Figure 6-7 : VistaLINK® - Notify.....	52
Figure 6-8 : VistaLINK® - VLPro Header\Refresh.....	53
Figure 6-9 : VistaLINK® - VLPro Header\Auto refresh .....	53
Figure 6-10 : VistaLINK® - VLPro Header\Apply .....	53
Figure 6-11 : VistaLINK® - VLPro Header\Dynamic Apply .....	53
Figure 6-12 : VistaLINK® - Select Hardware .....	54
Figure 6-13 : VistaLINK® - Upgrade Card .....	55
Figure 7-1 : Card Front View .....	58
Figure 8-1 : WebEASY® - TX Side .....	59
Figure 8-2 : WebEASY® - RX Side .....	60
Figure 8-3 : WebEASY® - TX Side .....	61
Figure 8-4 : WebEASY® - RX Side.....	61

## REVISION HISTORY

<u>REVISION</u>	<u>DESCRIPTION</u>	<u>DATE</u>
1.0	Initial start-up guide creation	June 2016
1.1	Manual release	Sept 2016
2.1	Updates throughout	Sept 2016
2.2	Updates throughout	Nov 2016
2.3	Updates Throughout	Apr 2017

Information contained in this manual is believed to be accurate and reliable. However, Evertz assumes no responsibility for the use thereof nor for the rights of third parties, which may be effected in any way by the use thereof. Any representations in this document concerning performance of Evertz products are for informational use only and are not warranties of future performance either express or implied. The only warranty offered by Evertz in relation to this product is the Evertz standard limited warranty, stated in the sales contract or order confirmation form.

Although every attempt has been made to accurately describe the features, installation and operation of this product in this manual, no warranty is granted nor liability assumed in relation to any errors or omissions unless specifically undertaken in the Evertz sales contract or order confirmation. Information contained in this manual is periodically updated and changes will be incorporated into subsequent editions. If you encounter an error, please notify Evertz Customer Service department. Evertz reserves the right, without notice or liability, to make changes in equipment design or specifications.

*This page left intentionally blank*

## 1. INTRODUCTION

With the improved speed and reliability of IP networks the 7890IXG provides an ideal option for delivering high-quality contribution video over unmanaged IP networks. The 7890IXG features a unique Forward Error Correction mechanism (+FEC option) that allows for a seamless error free delivery of audio and video streams over any network that has not been optimized for media transport.

The 7890IXG module is VistaLINK® capable, offering remote monitoring, control and configuration capabilities via Simple Network Management Protocol (SNMP) giving the flexibility to manage operations, including signal monitoring and module configuration from SNMP capable control systems (VistaLINK® PRO NMS).

The 7890IXG is a one slot card that can be housed in 7800FR or 7800FR-QT frames which have a 15 slot capacity. The 7890IXG brings flexibility, performance, and feasibility in a single module.





Figure 1-1 : 7890IXG Network Management

### Features & Benefits

- Broadcast Quality Transport Over unmanaged IP networks
- Advanced rate control for maximum link utilization
- Stream secured using high-strength encryption (+AES128 option for encryption)
- Fast media services launch
- Supports IP and ASI transport streams
- VistaLINK® capable for remote monitoring, control and configuration capabilities via SNMP
- Redundant power supply chassis
- Hot-swappable module without need for re-cabling in event of failure
- Portable or rack mounted frame assemblies

- High density approach offers 15 modules within 3RU applications
- Low cost media contribution over unmanaged IP networks
- Low cost redundancy option for primary dedicated media delivery links
- Fast deployment of ad-hoc media services



**Figure 1-2 : Block Diagram (Typical Configuration)**

## 2. GETTING STARTED




Figure 2-1 : 7890IXG Rear Panel

- SFP Internet:** Ethernet port used for transferring and receiving data through unmanaged networks. For example: the Internet.
- LN/ACT SPD:** Ethernet Access 1 and 2 ports are used to interface the transport stream onto the unmanaged network. For example these ports will interface with an encoder and/or decoder for access to and from the internet.
- ASI IN/OUT:** ASI input and output BNC.
- USB:** This port allows the user to directly access the module serially by connecting directly to a computer through USB cable. This USB port allows serial port access for initial setup.

*This page left intentionally blank*

### 3. SPECIFICATIONS

**Inputs & Outputs:**

- 1 x DVB-ASI Input per DVB TR 101 891 (future release)
- 1 x DVB-ASI Output per DVB TR 101 891 (future release)
- 1 x SFP 10/100/1000 GigE I/O for MPEG-2 TS over IP
- 2 x RJ45 10/100 for transport stream subscription/delivery and card control

**Network Interface:**

<b>Standard</b>	Ethernet 10/100 base-T
	IEEE 802.3U standard for 100Mb/s
<b>Connector</b>	RJ-45

**Network Management:**

<b>Control</b>	HTTP web browser
	True SNMP with VistaLINK®
	Serial RS-232 at card edge for initial setup
	USB at card rear for initial setup

**Monitoring:**

<b>Signal Detection</b>	Signal Presence Detection
<b>Error Notification</b>	HTTP web browser status page
	SNMP Trap notification
	Card edge LED

**Electrical:**

<b>Voltage</b>	+12V DC
<b>Power</b>	18W
<b>EMI/RFI</b>	Complies with FCC Part 15
	Class A EU EMC Directive

**Physical (number of slots):**

<b>7700FR-C</b>	1
<b>7800FR</b>	1
<b>7800FR-QT</b>	1

*This page left intentionally blank*

## 4. SETUP GUIDE

This section will outline initial network management setup and transmission of the 7890IXG module. Basic setup of a single transmit to a single receiver is outlined.

### 4.1. INITIAL SETUP USING SERIAL PORT OR USB PORT

- Power up the card in the frame.
- Connect serial port J4 on the card (via the provided 4-pin rainbow colored cable) or USB port on rear plate via USB cable to a PC to directly access the initial settings of the card.
- On the PC, Open serial port terminal program and use the following settings.

Baud	<b>115200</b>
Data bits	<b>8</b>
Parity	<b>no</b>
Stop bits	<b>1</b>
Flow Control	<b>no</b>

- This will take you to the serial login page and will allow you to access the initial settings of the card.





Figure 4-1 : Tera Term Login

- Type login: customer and password: customer.

- Type 1 to go to network setup, 2 for SNMP setup, and 3 for engineering debug tool and press enter. For example if you want to change the IP address of the card, type 1 and press enter.



**Figure 4-2 : Menu Screen**

```
(1) Network Setup
(2) SNMP Setup
(3) Engineering Debug Tool

(X) Save and Exit
(W) Exit without Saving

> 1

*****
* WARNING: *
* Improper changes to IP addresses may affect *
* network configuration. Incorrect IP addresses *
* could potentially affect other devices on the *
* network. It is good practice to confirm *
* validity of all IP addresses with your IT/IS *
* departments prior to configuration. *
*****
```

---

```
**** Network Setup ****

(1) IP Address [192.168.8.76]
(2) Netmask [255.255.255.0]
(3) Gateway [192.168.8.1]
(4) Broadcast [192.168.8.255]

(X) Exit
```

### **Figure 4-3 : Network Setup**

- To change the IP address type 1 and hit enter. To change the netmask, gateway, or broadcast type the corresponding number and hit enter. After selecting an option type the desired address and press enter. To save the new settings type ‘S’ and hit enter.
- For changing the SNMP setup and engineering debug tool, follow the same steps as network setup.

## 4.2. LICENSING



**Note:** Licenses should be preloaded from the factory, however, if additional licenses are required, please contact the factory for assistance (not having accurate license files cause unexpected input and output availability).

Make sure the license installed was ordered correctly. If not, the user will need to upgrade the license file. Upgrading the license can be done from Web-Easy or VLPro. Both have same procedure to upgrade the license file.

### 4.2.1. Upgrading License Using Webeasy


To upgrade the license from Web-Easy, enter the IP address of the 7890IXG card in the web browser then enter the login and password (default is set to customer, customer).

After entering into the webpage, click on system tab on the left and then click on Browse under License control tab (Figure 4-4).

The screenshot shows the 'System' tab in the WebEASY interface. On the left, there's a sidebar with 'System' selected, followed by 'IP Input', 'Internet', 'Internet Output IP Stream', 'Internet Input IP Stream', 'Server', and 'Notify'. The main area has three sections: 'Information', 'License Control', and 'Configuration Management'. In the 'License Control' section, there are fields for 'Product License File' (with a 'Browse...' button highlighted with a red box), 'Product Mac Address' (containing '00:02:c5:1a:01:ec'), and 'Upload' and 'Download' buttons. Below that is the 'Configuration Management' section with 'Import Configure File', 'Export Configure File', 'Import Presets File', and 'Export Presets File' fields, each with its own 'Browse...', 'Upload', and 'Download' buttons. At the bottom is the 'Control' section with a 'Card Reboot' button. The footer includes the Evertz logo, a note about being powered by everb1.4, and links for 'Info/Logging', 'Users', and a question mark icon.

Figure 4-4 : WebEASY<sup>®</sup> - System Tab\License Upgrade

Locate and select the license file (.IXG extension) and click open.



**Figure 4-5 : WebEASY<sup>®</sup> - License Upload**

Click upload and license will be upgraded.

#### 4.2.2. Upgrading License Using VLPro

To Upgrade the license through VLPro, Open VLPro and right click on the card IP address and click view configuration. This will take the user to a similar page as web-Easy.

Go to system tab and click on choose file under License control (Figure 4-6). Locate and select the file. Click open and then upload through VLPro. The file will then be uploaded.




Figure 4-6 : VistaLINK® - System Tab\License Upgrade

#### 4.3. SETUP COMMUNICATION BETWEEN TX SIDE AND RX SIDE

The 7890IXG is a powerful module which gives users the capability to transport video streams over lossy networks such as the internet. This section outlines the basic procedure to configure a transmitting and receiving 7890IXG to pass video over a network. Each IXG module has the ability to do multiple transmit and receive videos based on what type of license is installed. Setup of each transmit and receive port is identical to that outlined in this setup guide.

To start passing data between the ports, IP address configuration is required. Follow these steps to set up communication between Side 1 (TX) and Side 2 (RX).

##### 4.3.1. Side 1 (TX)

- Go to the webpage and click on the IP input tab to check port link status ( port link status shows the connection between the video source and access port of the card). “Up” status means it is connected the network that is hosting the source video. Please verify the connection from the IXG to the source network if the port status is “down.”
- Check the link speed and data rate. This will confirm the communication between the card and the source.

The screenshot shows the 'IP Input' tab of the WebEASY interface. On the left, a sidebar menu includes 'System', 'IP Input' (which is selected and highlighted in yellow), 'Internet', 'Internet Output IP Stream', 'Internet Input IP Stream', 'Server', and 'Notify'. The main content area has two sections: 'Access Port Control' and 'Access Port Monitor'. In 'Access Port Control', tabs for '1' and '2' are shown, with '1' selected. It contains fields for 'IP Address' (192.168.8.75), 'Netmask' (255.255.255.0), and 'Gateway' (192.168.8.1). In 'Access Port Monitor', tab '1' is selected, showing port link status as 'Up'. Below it is a table of port monitoring statistics:

Port Link Status	Up
Port Link Speed	100 Mbps
Port Rx Data Rate	54.568 Mbps
Port Rx Good Frames	4,872,062
Port Rx Error Frames	0
Port Tx Data Rate	0.000 Mbps
Port Tx Good Frames	911

A 'Clear Stats' button is located at the bottom of the monitor section. At the bottom of the page, there is footer text: 'Evertz Microsystems (powered by ewb v1.4)' and navigation links: 'Info/Logging', 'Users', and '?'. The entire interface has a dark grey background.

Figure 4-7 : WebEASY<sup>®</sup> - IP Input Tab

- After checking the access port link on the Transmitter side (TX side), verify the IP configuration of internet port on both TX side and Receiver side (RX side). “Destination IP” on the TX side under Stream Control under Internet output IP stream should match the “source IP” of the RX side under Internet tab (for example if the RX side is directly connected to the Internet, then this IP is the public internet IP of the TX side).

**evertz 7890IXG** Refresh Apply Dynamic Apply Upgrade Logout root

**System**  
**IP Input**  
**Internet**  
**Internet Output IP Stream** (selected)  
**Internet Input IP Stream**  
**Server**  
**Notify**

## Internet Output IP Stream

**Stream Control**

Profile Name	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)	Restart
Output IP Stream 1	TX	232.0.77.1	1,234	192.168.100.2!	10,000	7,020

**Stream Status**

Name	Running
Output IP Stream 1	TX Yes

**Receive Status**

Port	Bit Rate <i>bps</i>	Packet Loss	Total Packets	
Output IP Stream 1	1,234	50,460,366	0	5,043,013

**Transmit Status**

UDP Port	ARQ Port	Bit Rate <i>bps</i>	Total Packets	Receivers
Output IP Stream 1	10,000	7,020	50,916,334	192.168.100.2!

Evertz Microsystems (powered by ewb v1.4). ! Info/Logging Users ?

Figure 4-8 : WebEASY® - TX Side

**Internet Port Control**

IP Address	192.168.100.200
Netmask	255.255.255.0
Gateway	192.168.100.1
DHCP	Off
Speed Switch	100 Mbps

**Internet Port Monitor**

Internet Link Status	Up
Internet Link Speed	100 Mbps
Internet Rx Data Rate	55.936 Mbps
Internet Rx Good Frames	4,398,342
Internet Rx Error Frames	0
Internet Tx Data Rate	0.000 Mbps
Internet Tx Good Frames	119

**Buffer Control**

Echo Port	7 (0 to 65535)
Tx Buffers	4 K buffers (6 . 3 M B per proxy)
Rx Buffers	4 K buffers (6 . 3 M B per proxy)

Evertz Microsystems (powered by ezt v.1.4). ! Info/Logging Users ?

**Figure 4-9 : WebEASY<sup>®</sup> - RX Side**

- Also check for Destination UDP port and ARQ port on TX side should match with the source UDP port and ARQ port on the RX side.

evertz 7890IXG Refresh Apply Dynamic Apply Upgrade Logout root

**Internet Output IP Stream**

**Stream Control**

Profile Name	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)	Restart
Output IP Stream 1	TX	232.0.77.1	1,234	192.168.100.21	10,000	7,020

**Stream Status**

Name	Running
Output IP Stream 1	TX Yes

**Receive Status**

Port	Bit Rate bps	Packet Loss	Total Packets
Output IP Stream 1	1,234	50,448,684	0 5,662,475

**Transmit Status**

UDP Port	ARQ Port	Bit Rate bps	Total Packets	Receivers
Output IP Stream 1	10,000	7,020	50,904,545	5,662,554 192.168.100.21

Evertz Microsystems (powered by ewb v1.4). Info/Logging Users ?

**Figure 4-10 : WebEASY<sup>®</sup> - TX Side**

**Stream Control**

Input IP Stream 1	Stream Name RX	Restart
-------------------	-------------------	---------

**Network**

Input IP Stream 1	ARQ Enable ARQ	Destination IP Address 232.0.77.1	Destination UDP Port 1,234	Source UDP Port <b>10,000</b>	Expected Jitter 50
-------------------	-------------------	--------------------------------------	-------------------------------	----------------------------------	-----------------------

**ARQ**

Input IP Stream 1	ARQ Port <b>7,020</b>	ARQ Mode Auto	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535) ms	Target Latency (0 to 2147483647) ms	Max Burst Drop (0 to 2147483647) ms	Multi-Retransmit Mode Enable
-------------------	--------------------------	------------------	------------------------------------	---------------------------------------	--	--	---------------------------------

**Monitoring**

Input IP Stream 1	Name RX	Running Yes
-------------------	------------	----------------

**Network Status**

Input IP Stream 1	Sender IP 192.168.100.11	Port 10,000	Bit Rate bps 52,504,803	Packet Loss 0	Jitter 0	Dropped 0	Total Pac 5,910,447
-------------------	-----------------------------	----------------	-------------------------------	------------------	-------------	--------------	------------------------

**ARQ Status**

Input IP Stream 1	Unrecovered 0	Recovered 0	Max Burst Loss Packets 0	Port 7,020
-------------------	------------------	----------------	-----------------------------	---------------

**Figure 4-11 : WebEASY® - RX Side**

- To send specific data to the RX SIDE over the internet, enter the IP address of the source data in “Multicast subscription address” under stream control section under Internet output IP stream tab on the TX Side webpage.

#### 4.3.2. Side 2 (RX)

- Go to the webpage and click on IP input tab and check port link status ( port link status shows the connection between the source and access port of the card). “Up” status means it is connected to the destination network. Please verify the connection from the IXG to the destination network if the port status is “down.”
- Also check the link speed and data rate. This will confirm the communication between the card and the destination.

The screenshot shows the 'IP Input' configuration page for the 7890IXG. The left sidebar has tabs for System, IP Input (selected), Internet, Internet Output IP Stream, Internet Input IP Stream, Server, and Notify. The main area has two sections: 'Access Port Control' and 'Access Port Monitor'. In 'Access Port Control', port 1 is selected, showing IP Address (192.168.8.76), Netmask (255.255.255.0), and Gateway (192.168.8.1). In 'Access Port Monitor', port 1 is selected, showing Port Link Status (Up, highlighted with a red box), Port Link Speed (100 Mbps), Port Rx Data Rate (0.000 Mbps), Port Rx Good Frames (1,192), Port Rx Error Frames (0), Port Tx Data Rate (55.384 Mbps), and Port Tx Good Frames (6,991,435). A 'Clear Stats' button is at the bottom.

**Figure 4-12 : WebEASY<sup>®</sup> - IP Input**

- After checking the access port link on the RX side, verify the IP configuration of the internet ports on both the TX and RX sides. The “Destination IP” on the TX side (under the Internet Output IP stream tab) must match the “Source IP” of the RX side (under the Internet tab). For example: if the TX side is directly connected to the Internet, then this IP is the public internet IP of the RX side.




Figure 4-13 : WebEASY® - TX SIDE




Figure 4-14 : WebEASY® - RX SIDE

- The Source UDP and ARQ ports on the RX side should match with the destination UDP and ARQ ports on the TX side.

evertz 7890IXG Refresh Apply Dynamic Apply Upgrade Logout root

## Internet Input IP Stream

### Stream Control

	Stream Name	Enable	Restart
Input IP Stream 1	RX_proxy1	Enable ▾	<b>Restart</b>
Input IP Stream 2	RX_proxy2	Enable ▾	<b>Restart</b>
Input IP Stream 3	RX_proxy3	Enable ▾	<b>Restart</b>
Input IP Stream 4	RX_proxy4	Enable ▾	<b>Restart</b>

### Network

	ARQ Enable	Destination IP Address	Destination UDP Port (0 to 65535)	Source UDP Port (0 to 65535)	Expected Jitter (0 to 65535)
Input IP Stream 1	ARQ ▾	239.0.0.0	2,222	<b>20,000</b>	50
Input IP Stream 2	ARQ ▾	239.0.0.1	1,234	30,000	50
Input IP Stream 3	ARQ ▾	192.168.255.2	10,000	1,234	50
Input IP Stream 4	ARQ ▾	192.168.255.2	10,000	1,234	50

### ARQ

	ARQ Port (0 to 65535)	ARQ Mode	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535)	Target Latency (0 to 65535) ms	Max Burst Drop (0 to 2147483647) ms	Multi-Retransmit Mode
Input IP Stream 1	<b>20,000</b>	Auto ▾		750	40	Enable ▾	
Input IP Stream 2	30,000	Auto ▾		750	40	Enable ▾	
Input IP Stream 3	7,020	Auto ▾		750	40	Enable ▾	
Input IP Stream 4	7,020	Auto ▾		750	40	Enable ▾	

### FEC

Input IP Stream 1	10,002
Input IP Stream 2	12,002
Input IP Stream 3	10,002

Figure 4-15 : WebEASY® - RX Side

evertz 7890IXG Refresh Apply Dynamic Apply Upgrade Logout root

## Internet Output IP Stream

### Stream Control

	Profile Name	Enable	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)
Output IP Stream 1	TX_proxy1	Enable ▾	239.0.0.0	2,222	192.168.100.11	<b>20,000</b>	<b>20,000</b>
Output IP Stream 2	TX_proxy2	Enable ▾	239.0.0.1	1,234	192.168.100.11	30,000	30,000
Output IP Stream 3	TX_proxy3	Disable ▾	239.0.0.1	1,234	192.168.100.11	30,000	30,000
Output IP Stream 4	TX_proxy4	Disable ▾	239.0.0.0	2,222	192.168.255.2	20,000	7,020

Figure 4-16 : WebEASY® - TX Side

#### 4.4. TROUBLESHOOTING

After following the set up procedure, if the user does not see a signal on the receiver side troubleshooting is required. Basic troubleshooting is outlined, for in depth troubleshooting please contact Evertz service.

##### 4.4.1. No Signal communication between TX side and source:

Signal Communication between the TX side and source can be confirmed by going to the IP Input Tab on the webpage and looking under Access Port Monitor. Check the link Up/Down status. It must be Up, if the link is Down please verify source connectivity.

The screenshot shows the 'IP Input' section of the WebEASY® interface. On the left, a sidebar menu includes 'System', 'IP Input' (which is selected and highlighted in green), 'Internet', 'Internet Output IP Stream', 'Internet Input IP Stream', 'Server', and 'Notify'. The main content area has two tabs: 'Access Port Control' and 'Access Port Monitor'. Under 'Access Port Control', there are fields for 'IP Address' (192.168.8.76), 'Netmask' (255.255.255.0), and 'Gateway' (192.168.8.1). Under 'Access Port Monitor', there are two tabs for 'Access Port 1' and 'Access Port 2'. The 'Access Port 1' tab is active, showing the following data:

Port Link Status	Up
Port Link Speed	100 Mbps
Port Rx Data Rate	0.000 Mbps
Port Rx Good Frames	1,192
Port Rx Error Frames	0
Port Tx Data Rate	55.384 Mbps
Port Tx Good Frames	6,991,435

A red box highlights the 'Up' status in the first row. A 'Clear Stats' button is located at the bottom of the table.

Figure 4-17 : WebEASY® - IP Input

If the link is Down and there is no signal communication between the TX side and the source, the user should check connectivity by connecting to the source path. If the path is good, check that the multicast subscription address matches with the desired source address.

#### 4.4.2. No Signal communication between RX side and Destination:

Signal Communication between the RX side and Destination can be confirmed by going to the IP Input Tab on the webpage and looking under Access Port Monitor. Check the link Up/Down status. It must be Up, if the link is Down please verify source connectivity.

The screenshot shows the 'IP Input' section of the WebEASY® interface. On the left, a sidebar menu includes 'System', 'IP Input' (which is selected and highlighted in green), 'Internet', 'Internet Output IP Stream', 'Internet Input IP Stream', 'Server', and 'Notify'. At the top right are buttons for 'Logout' and 'root'. The main area has two tabs: 'Access Port Control' and 'Access Port Monitor'. Under 'Access Port Control', there are fields for 'Access Port' (set to 1), 'IP Address' (192.168.8.76), 'Netmask' (255.255.255.0), and 'Gateway' (192.168.8.1). Under 'Access Port Monitor' (with 'Access Port' set to 1), there is a table of statistics:

Access Port	1	2
Port Link Status	Up	
Port Link Speed	100 Mbps	
Port Rx Data Rate	0.000	Mbps
Port Rx Good Frames	1,192	
Port Rx Error Frames	0	
Port Tx Data Rate	55.384	Mbps
Port Tx Good Frames	6,991,435	

A red box highlights the 'Up' status in the first column of the Port Link Status row. A 'Clear Stats' button is located at the bottom right of the monitor table.

Figure 4-18 : WebEASY® - IP Input

If the link is Down and there is no signal communication between the RX side and the destination, check connectivity by connecting to the destination path. If the path is good, check that the multicast subscription address matches with the desired source address.

#### 4.4.3. TX Side Not Streaming with RX Side or Stream Not Received by RX Side

Check the Internet Output IP Stream tab on the TX side webpage. The following information should match with the Internet Input IP Stream tab on the RX side webpage:

**Stream Control**

	Profile Name	Enable	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)
Output IP Stream 1	TX_proxy1	Enable ▾	239.0.0.0	2,222	192.168.100.11	20,000	20,000
Output IP Stream 2	TX_proxy2	Enable ▾	239.0.0.1	1,234	192.168.100.11	30,000	30,000
Output IP Stream 3	TX_proxy3	Disable ▾	239.0.0.1	1,234	192.168.100.11	30,000	30,000
Output IP Stream 4	TX_proxy4	Disable ▾	239.0.0.0	2,222	192.168.255.2	20,000	7,020

**FEC**

	Row (0 to 65535)	Column (0 to 65535)	FEC Port (0 to 65535)
Output IP Stream 1	10	16	10,002
Output IP Stream 2	16	10	12,002
Output IP Stream 3	10	10	14,002
Output IP Stream 4	10	10	10,002

**Stream Status**

	Name	Running
Output IP Stream 1	TX_proxy1	Yes
Output IP Stream 2	TX_proxy2	Yes
Output IP Stream 3	TX_proxy3	No
Output IP Stream 4	TX_proxy4	No

Figure 4-19 : WebEASY® - Internet Output IP Stream

**everlitz 7890IXG** Refresh Apply Dynamic Apply Upgrade Logout root

**System**

**IP Input**

**Internet**

**Internet Output IP Stream**

**Internet Input IP Stream**

**Server**

**Notify**

## Internet Input IP Stream

### Stream Control

	Stream Name	Enable	Restart
Input IP Stream 1	RX_proxy1	Enable ▾	Restart
Input IP Stream 2	RX_proxy2	Enable ▾	Restart
Input IP Stream 3	RX_proxy3	Enable ▾	Restart
Input IP Stream 4	RX_proxy4	Enable ▾	Restart

### Network

	ARQ Enable	Destination IP Address	Destination UDP Port (0 to 65535)	Source UDP Port (0 to 65535)	Expected Jitter (0 to 65535)
Input IP Stream 1	ARQ ▾	239.0.0.0	2,222	20,000	50
Input IP Stream 2	ARQ ▾	239.0.0.1	1,234	30,000	50
Input IP Stream 3	ARQ ▾	192.168.255.2	10,000	1,234	50
Input IP Stream 4	ARQ ▾	192.168.255.2	10,000	1,234	50

### ARQ

	ARQ Port (0 to 65535)	ARQ Mode	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535)	Target Latency (0 to 2147483647) ms	Max Burst Drop (0 to 2147483647) ms	Multi-Retransmit Mode
Input IP Stream 1	20,000	Auto ▾		750	40		Enable ▾
Input IP Stream 2	30,000	Auto ▾		750	40		Enable ▾
Input IP Stream 3	7,020	Auto ▾		750	40		Enable ▾
Input IP Stream 4	7,020	Auto ▾		750	40		Enable ▾

### FEC

Input IP Stream 1	10,002
Input IP Stream 2	12,002

Figure 4-20 : WebEASY® - Internet Input IP Stream

If any of the settings are mismatched the signal will not go through. Please ensure all settings are configured correctly.

#### 4.4.4. Data Loss on RX Side:

The numbers of unrecovered (Data Lost) and recovered (Data Saved) Input data packets received by the RX side can be detected by going to the “Internet Input IP stream” tab on the RX side webpage at the bottom under “ARQ Status.” “Unrecovered” means the data packets were dropped and lost by the RX side. Recovered signifies the number of data packets that the RX side has successfully recovered. For best operation, the number of unrecovered packets should always be 0. If this is not the case, verify the configuration settings between the TX and RX sides and check the Bitrate at both ends (Transmit status (TX), Network Status (RX)). If the bitrate and all configurations match and there is still data loss(unrecovered), the user may increase the Target Latency number. This will delay the time process of the RX side card (Please note: This setting will reduce the number of unrecovered data packets but will also add latency between TX and RX side).

**Stream Control**

Input IP Stream 1	Stream Name RX	Restart
-------------------	-------------------	---------

**Network**

Input IP Stream 1	ARQ Enable ARQ	Destination IP Address 232.0.77.1	Destination UDP Port (0 to 65535) 1,234	Source UDP Port (0 to 65535) 10,000	Expected Jitter (0 to 65535) 50
-------------------	-------------------	--------------------------------------	---	---	---------------------------------------

**ARQ**

Input IP Stream 1	ARQ Port (0 to 65535) 7,020	ARQ Mode Auto	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535) 750	Target Latency (0 to 65535 ms) 750	Max Burst Drop (0 to 2147483647) ms 40	Multi-Retransmit Mode Enable
-------------------	-----------------------------------	------------------	------------------------------------	---	--	--	---------------------------------

**Monitoring**

Input IP Stream 1	Name RX	Running Yes
-------------------	------------	----------------

**Network Status**

Input IP Stream 1	Sender IP 192.168.100.1	Port 10,000	Bit Rate bps 52,505,768	Packet Loss 0	Jitter 0	Dropped 0	Total Pac 7,608,518
-------------------	----------------------------	----------------	-------------------------------	------------------	-------------	--------------	------------------------

**ARQ Status**

Input IP Stream 1	Unrecovered 0	Recovered 0	Max Burst Loss Packets 0	Port 7,020
-------------------	------------------	----------------	-----------------------------	---------------

Figure 4-21 : WebEASY® - Internet Input IP Stream

#### 4.4.5. VLPro not detecting the card

If VLPro is not detecting the card, Please check following:

**VistaLINK® Version** – Please check the VistaLINK® version to ensure it matches the requirements. The VistaLINK® version can be verified by clicking on the help menu at the top of the VLPro server and selecting “About.” See Figure 4-22.





Figure 4-22 : VistaLINK® - VLPro version


If the current VistaLINK® version does not match the required version, please upgrade the version by upgrading both the VLPro server and VLPro client.

**Jar File** – If your VistaLINK® version is as per the requirement, please verify that VistaLINK® has the correct jar file for the IXG card (Please Note: The same jar file is required for both the TX side and RX side). To verify the jar file right click on the IP Address of the IXG card in the VLPro client and then click on “Version Information.” See Figure 4-23.



**Figure 4-23 : VistaLINK® - Hardware**

Click on the IP address of the desired card. The version indicates the jar file version of the card.



**Figure 4-24 : VistaLINK® - Jar Version**

**Upgrade Jar** – If the Jar file does not match the required version, please upgrade the jar file from the VLPro server by clicking on the help menu and selecting “Apply Update” and then the product. Locate and select the jar file that needs to be upgraded, after selecting the .jar file click open and then upgrade. The VLPro server and client will restart automatically.




Figure 4-25 : VistaLINK® - Select Jar

#### 4.4.6. Web page not responding

If the webpage is not responding to the IXG card then the user should do the following:

- Verify by using a different browser (Mozilla Firefox or Chrome recommended).
- If the Card still does not respond, check the Ethernet connection, network settings of the card and computer network settings. Management PC should have access to the management subnet where the card is situated. Also verify that no IP conflict exists on the management network.

If all the network settings and Ethernet ports are correctly set up reboot the card from VLPro (note: The user can also repower the card by unplugging it and plugging it back in if the user does not have VistaLINK®).

*This page left intentionally blank*

## 5. WEBEASY REFERENCE CONTROLS

### 5.1. SYSTEM




Figure 5-1 : WebEASY<sup>®</sup> - System Page

#### 5.1.1. Information

**Product Name:** This parameter displays the product name.

**Firmware Version:** This parameter displays the firmware version.

**Serial Number:** This parameter displays the serial number.

**Up Time:** This parameter returns the up time for the 7890IXG.

#### 5.1.2. License Control

**Product License File:** This control allows the user to select and upload a product license file.

**Product Mac Address:** This parameter displays the card MAC address.

#### 5.1.3. Configuration Management

**Import Configure File:** This control allows the user to select and upload a JSON configuration file to card.

**Export Configure File:** This control allows the user to save configuration data to a JSON file, and download the JSON file to a local host.

**Import Presets File:** This control allows the user to select and upload a preset file to the card.

**Export Presets File:** This control allows the user to save configuration data to a preset file, and download the preset file to a local host.

#### 5.1.4. Control

**Card Reboot:** This control allows the user to reboot the card.

### 5.2. IP INPUT

The screenshot shows the 'IP Input' page of the WebEASY interface. It is divided into two main sections: 'Access Port Control' and 'Access Port Monitor'.

**Access Port Control:**

Access Port	1	2
IP Address	192.168.254.119	
Netmask	255.255.192.0	
Gateway	192.168.254.111	

**Access Port Monitor:**

Access Port	1	2
Port Link Status	Up	
Port Link Speed	100 Mbps	
Port Rx Data Rate	0.016	Mbps
Port Rx Good Frames	2,787,829	
Port Rx Error Frames	0	
Port Tx Data Rate	0.000	Mbps
Port Tx Good Frames	20,361	
<b>Clear Stats</b>		

Figure 5-2 : WebEASY<sup>®</sup> - IP Input

#### 5.2.1. Access Port Control

**IP Address:** This parameter allows the user to set the IP Address for the data port.

**Netmask:** This parameter allows the user to set the netmask for the data port.

**Gateway:** This parameter allows the user to set the gateway for the data port.

#### 5.2.2. Access Port Monitor

**Port Link Status:** This parameter returns the port link status: up or down.

**Port Link Speed:** This parameter returns the port link speed: down, spd10, spd100, spd1ge.

**Port RX SIDE Data Rate:** This parameter returns the port RX SIDE data rate.

**Port RX SIDE Good Frames:** This parameter returns the amount of good port RX SIDE frames.

**Port RX SIDE Error Frames:** This parameter returns the amount of error port RX SIDE frames.

**Port TX SIDE Data Rate:** This parameter returns the port TX SIDE data rate.

**Port TX SIDE Good Frames:** This parameter returns the amount of good port TX SIDE frames.

**Clear Stats:** This control allows the user to clear all stats.

### 5.3. INTERNET

**Internet**

**Internet Port Control**

IP Address	192.168.243.33
Netmask	255.255.255.0
Gateway	192.168.243.47
DHCP	On
Speed Switch	1000 Mbps

**Internet Port Monitor**

Internet Link Status	Down
Internet Link Speed	Down
Internet Rx Data Rate	0.000 Mbps
Internet Rx Good Frames	0
Internet Rx Error Frames	0
Internet Tx Data Rate	0.000 Mbps
Internet Tx Good Frames	17

**Buffer Control**

Echo Port	7 <small>(0 to 65535)</small>
Tx Buffers	4 K buffers (6 . 3 M B per proxy)
Rx Buffers	4 K buffers (6 . 3 M B per proxy)

Figure 5-3 : WebEASY<sup>®</sup> - Internet

#### 5.3.1. Internet Port Control

**IP Address:** This parameter allows the user to set the IP Address for the control port.

**Netmask:** This parameter allows the user to set the netmask for the control port.

**Gateway:** This parameter allows the user to set the gateway for the control port.

**DHCP:** This control enables or disables DHCP.

**Speed Switch:** This control allows the user to change the switch speed.

### **5.3.2. Internet Port Monitor**

**Internet Link Status:** This parameter returns the internet link status: up or down.

**Internet Link Speed:** This parameter returns the internet link speed: down, spd10, spd100, spd1ge

**Internet RX SIDE Data Rate:** This parameter returns the internet RX SIDEdata rate.

**Internet RX SIDE Good Frames:** This parameter returns the amount of good internet RX SIDE frames.

**Internet RX SIDE Error Frames:** This parameter returns the amount of error internet RX SIDE frames.

**Internet TX SIDE Data Rate:** This parameter returns the internet TX SIDEdata rate.

**Internet TX SIDE Good Frames:** This parameter returns the amount of good internet TX SIDE frames.

**Clear Stats:** This control allows the user to clear all stats.

### **5.3.3. Buffer Control**

**Echo Port:** This parameter allows the user to select the echo port for the ARQ Qos Proxy.

**TX SIDE Buffers:** This parameter allows the user to select the TX SIDE Buffers for the ARQ Qos Proxy: k4, k8, k16, k32.

**RX SIDE Buffers:** This parameter allows the user to select the RX SIDE Buffers for the ARQ Qos Proxy: k4, k8, k16, k32.

#### 5.4. INTERNET INPUT IP STREAM

**Internet Input IP Stream**

Stream Control					
Input IP Stream 1	Stream Name Rx_proxy1	Restart			
Input IP Stream 2	Rx_proxy2	Restart			
Input IP Stream 3	Rx_proxy3	Restart			

Network					
	ARQ Enable	Destination IP Address	Destination UDP Port (0 to 65535)	Source UDP Port (0 to 65535)	Expected Jitter (0 to 65535)
Input IP Stream 1	ARQ ▾	192.168.255.1	10,000	20,000	50
Input IP Stream 2	ARQ ▾	192.168.255.1	10,000	20,000	50
Input IP Stream 3	ARQ ▾	192.168.255.1	10,000	20,000	50

ARQ						
	ARQ Port (0 to 65535)	ARQ Mode	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535)	Target Latency (0 to 65535) ms	Max Burst Drop (0 to 2147483647) ms
Input IP Stream 1	7,020	Auto ▾		750	40	Enable ▾
Input IP Stream 2	7,020	Auto ▾		750	40	Enable ▾
Input IP Stream 3	7,020	Auto ▾		750	40	Enable ▾

Monitoring					
	Name	Running			
Input IP Stream 1	Rx_proxy1	Yes			
Input IP Stream 2	Rx_proxy2	Yes			
Input IP Stream 3	Rx_proxy3	Yes			

Network Status						
	Sender IP	Port	Bit Rate bps	Packet Loss	Jitter	Dropped
Input IP Stream 1	nodata	20,000	0	0	0	0
Input IP Stream 2	nodata	20,000	0	0	0	0
Input IP Stream 3	nodata	20,000	0	0	0	0

ARQ Status				
	Unrecovered	Recovered	Max Burst Loss Packets	Port
Input IP Stream 1	0	0	0	7,020
Input IP Stream 2	0	0	0	7,020
Input IP Stream 3	0	0	0	7,020

Figure 5-4 : WebEASY® - Internet Input IP Stream

#### 5.4.1. Stream Control

**Stream Name:** This parameter displays the RX side IP Stream profile name.

**Restart:** This control allows the user to restart the individual RX side IP Stream.

#### 5.4.2. Network

**ARQ Enable:** This parameter allows the user to select the RX side IP Stream IP Transport Mode: ARQ or RTP. ARQ enables retransmissions so should normally be enabled when transmitting over the public internet or similar lower reliability networks.

**Destination IP Address:** This parameter allows the user to set the RX side IP Stream Network Destination IP address. This means the IP address that the received transport stream will be output on to the access port.

**Destination UDP Port:** This parameter allows the user to set the RX side IP Stream Network Destination port number. This means the IP address that the received transport stream will be output on to the access port.

**Source UDP Port:** This parameter allows the user to set the RX side IP Stream Network Source UDP port number. This means the UDP port that the received transport stream will be output on to the access port.

**Expected Jitter:** This parameter allows the user to set the RX side IP Stream Network which expected the jitter for the WAN network.

#### 5.4.3. ARQ

**ARQ Port:** This parameter allows the user to set the RX side IP Stream ARQ port. This must match the ARQ port on the transmitting 7890IXG or Evertz Cloudbridge. By default, ARQ normally sends upstream retransmission request packets on UDP port 7020. The ARQ Port setting can be changed to any valid and non-conflicting UDP port. However, the same port number at both the encoder and the decoder should be defined. To help bypass firewall blocking, reset this to be the same port as the media UDP port, usually 10000.

**ARQ Mode:** This parameter allows the user to set the RX side IP Stream ARQ mode: Auto or Manual. Auto will attempt to pick appropriate values based on network conditions, while manual gives the user full control over retransmission parameters. When AUTO is set, you cannot set the number of retransmits or the round trip latency.

**Number Retransmits:** This parameter allows the user to set the RX side IP Stream ARQ Manual Mode maximum number of retransmissions when packet loss is detected. Higher values give more protection but increase the latency.

**Round Trip Latency:** This parameter allows the user to set the RX side IP Stream ARQ Manual Mode Round Trip Time, if it is known.

**Target Latency:** Target Latency, specifies the total delay, in milliseconds, allotted for the request, retransmission, and recovery process. The ARQ mechanism will attempt as many retries as possible within this target latency time. Thus, larger target latency times increase the delay before video is output, but allows for more chances of requesting and recovering any missing packets. The ARQ error correction operates through the addition of a small additional buffering delay to provide enough time to request and receive replacement for each lost packet. Target Latency gives the ARQ mechanism a target value for determining the necessary ARQ delay. The ARQ divides the Target Latency, specified in milliseconds, by the round-trip time to the video encoding source to determine the number of request attempts. Unless

Robust Mode is enabled, it sets a minimum ARQ latency of one round-trip time. A larger Target Latency allows the system to increase the number or repeat requests.

**Max Burst Drop:** A Burst Drop delay can also be specified to delay any retransmission requests for a time equal to the maximum expected packet loss time, such as from dynamic router changes or other sources of burst loss.

**Multi-Retransmit Mode:** This parameter allows the user to enable or disable RX side Proxy ARQ Auto Mode Robust Mode. This gives high performance for stream recovery with the tradeoff of more latency. Normally, the ARQ will only require that a minimum of one repeat request is sent to the video encoding source device, regardless of the Target Latency. However, enabling Robust Mode will increase the minimum number of repeat requests to a minimum of two retries.

#### 5.4.4. Monitoring

**Name:** This parameter displays the RX side IP Stream Name.

**Running:** This parameter returns whether the RX side IP Stream is running or not: Yes or No.

#### 5.4.5. Network Status

**Sender IP:** This parameter returns the RX side IP Stream Network Sender IP. For example this could be the IP address of the sending 7890IXG-T.

**Port:** This parameter returns the RX side IP Stream Network port number.

**Bit Rate:** This parameter returns the RX side IP Stream Network bit rate.

**Packet Loss:** This parameter returns the RX side IP Stream Network packet loss.

**Jitter:** This parameter returns the RX side IP Stream Network jitter. Packets in incoming IP packet streams may lose their ordering or suffer variable delays during transport through an IP network. The proxy receiver buffers all incoming video/IP packets in a buffer and reorders RTP encapsulated packets by RTP sequence number. This parameter specifies the size of this incoming packet buffer in milliseconds of delay. Specify 0 here to disable this additional buffering when latency needs to be minimize.

**Dropped:** This parameter returns the RX side IP Stream Network drops.

**Total Packets:** This parameter returns the RX side IP Stream Network total packets.

#### 5.4.6. ARQ Status

**Unrecovered:** This parameter returns the number of RX side IP Stream ARQ unrecovered packets.

**Recovered:** This parameter returns the number of RX side IP Stream ARQ recovered packets.

**Max Burst Loss Packets:** This parameter returns the number of RX side IP Stream ARQ max burst loss packets.

**Port:** This parameter returns the RX side IP Stream ARQ port number.

## 5.5. INTERNET OUTPUT IP STREAM

**Internet Output IP Stream**

Stream Control							
	Profile Name	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)	Restart
Output IP Stream 1	tx_proxy1		20,000	192.168.255.1	10,000	7,020	<b>Restart</b>
Output IP Stream 2	t		20,000	192.168.255.1	10,000	7,020	<b>Restart</b>
Output IP Stream 3	TX_proxy3		20,000	192.168.255.1	10,000	7,020	<b>Restart</b>

Stream Status		
	Name	Running
Output IP Stream 1	tx_proxy1	Yes
Output IP Stream 2	t	Yes
Output IP Stream 3	TX_proxy3	Yes

Receive Status				
	Port	Bit Rate <i>bps</i>	Packet Loss	Total Packets
Output IP Stream 1	20,000	0	0	0
Output IP Stream 2	20,000	0	0	0
Output IP Stream 3	20,000	0	0	0

Transmit Status					
	UDP Port	ARQ Port	Bit Rate <i>bps</i>	Total Packets	Receivers
Output IP Stream 1	10,000	7,020	0	0	192.168.255.1
Output IP Stream 2	10,000	7,020	0	0	192.168.255.1
Output IP Stream 3	10,000	7,020	0	0	192.168.255.1

**Figure 5-5 : WebEASY<sup>®</sup> - Internet Output IP Stream**

### 5.5.1. Stream Control

**Profile Name:** This parameter allows the user to set the name for the IP stream profile.

**MultiCast Subscription Address:** This parameter allows the user to set The Multicast IP address of the target transport stream entering the IP access port.

**Source UDP Port:** This parameter allows the user to set the UDP port for the transport stream entering the IP access port.

**Destination IP Address:** This parameter allows the user to set the Unicast IP address for the destination device. This would be the Evertz cloud software address, or the address of the 7890IXG-R that you wish to target.

**Destination UDP Port:** This parameter allows the user to set the Destination UDP port for the destination device. This would be the Evertz cloud software address or the address of the 7890IXG-R that you wish to target.

**ARQ Port:** This parameter allows the user to set ARQ port for retransmission requests over the internet. NOTE: Failure to set this, and allow it through any firewalls will prevent any retransmission requests, giving little to no protection for your stream. Make sure this value is different than any UDP port for video data.

**Restart:** This control allows the user to restart the individual TX side Proxy.

#### 5.5.2. Stream Status

**Name:** This parameter returns the name of the individual IP stream.

**Running:** This parameter returns whether the IP stream is running or not: Yes or No.

#### 5.5.3. Receive Status

**Port:** This parameter returns the IP Stream Receive port number.

**Bit Rate:** This parameter returns the IP Stream Received bit rate.

**Packet Loss:** This parameter returns the IP Stream Received packet loss.

**Total Packets:** This parameter returns the IP Stream Received total packets.

#### 5.5.4. Transmit Status

**UDP Port:** This parameter returns the IP Stream Transmit UDP port.

**ARQ Port:** This parameter returns the IP Stream Transmit ARQ Port.

**Bit Rate:** This parameter returns the IP Stream Transmit Bit rate.

**Total Packets:** This parameter returns the total number of IP Stream packets transmit.

**Receivers:** This parameter returns the IP Stream Transmit Receivers.

### 5.6. SERVER

The screenshot shows a 'Server' configuration page with three input streams. Each stream has a 'Use Server' dropdown menu set to 'No'. The columns are labeled 'Input IP Stream 1', 'Use Server', 'IP Address or Hostname', and 'Echo Port'.

Input IP Stream 1	Use Server	IP Address or Hostname	Echo Port
Input IP Stream 2	No		
Input IP Stream 3	No		

Figure 5-6 : WebEASY<sup>®</sup> - Server


#### 5.6.1. Server

**Use Server:** This parameter allows the user to enable or disable RX side Proxy Server Mode.

**IP Address or Hostname:** This parameter returns the RX side Proxy Server Mode IP address or hostname.

**Echo Port:** This parameter returns the RX side Proxy Server Mode Echo port number. NOTE: Please make sure this is different than ARQ and UDP data port numbers and that it can pass through any firewalls on the network.

## 5.7. NOTIFY



**Figure 5-7 : WebEASY<sup>®</sup> - Notify**

### 5.7.1. Output Notify

**Output Trap:** This control allows the user to enable or disable trap reporting.

**Output Faults:** This parameter returns the present state of a particular fault. The values for this object are false and true.

### 5.7.2. Input Notify

**Input Trap:** This control allows the user to enable or disable trap reporting.

**Input Faults:** This parameter returns the present state of a particular fault. The values for this object are false and true.

## 5.8. TRAPS

Description	Error
Output Proxy	Not present
Output Proxy Bandwidth	Over Limit
Input	Not present
Input Bandwidth	Over Limit

## 5.9. TOP MENU BAR

### 5.9.1. Refresh



Figure 5-8 : WebEASY<sup>®</sup> - Top menu bar\Refresh

Refresh tab is used to refresh the page. By clicking on Refresh, It allows any changes made by the user to the card to reflect on the webpage.

### 5.9.2. Apply



Figure 5-9 : WebEASY<sup>®</sup> - Top menu bar\Apply

Apply tab is used to implement any change through webpage. By clicking on apply, it allows to implement any change to the card through the webpage.

### 5.9.3. Dynamic Apply



Figure 5-10 : WebEASY<sup>®</sup> - Top menu bar\Dynamic Apply

Dynamic apply is used to implement changes automatically. This feature allows the user to automatically apply any change to the card through webpage

### 5.9.4. Upgrade

On the top of the web page for the 7890IXG, there is a tab labeled **Upgrade**. The **Upgrade** tab is used to check current firmware version and upload the latest firmware.



Figure 5-11 : WebEASY<sup>®</sup> - Top menu bar\Upgrade

Selecting the Upgrade tab, will take you to Figure 5-12 where the current firmware version is shown. Should the firmware version be outdated, you will need to download the firmware image file.




Figure 5-12 : WebEASY<sup>®</sup> - Firmware Upgrade



**NOTE:** Contact Evertz get the latest firmware file.

Select “Browse” to choose the .bin file. As in Figure 5-13, use the file browser to find the appropriate .bin file. Once a file is selected, click open and return to the Firmware Upgrade screen.




Figure 5-13 : WebEASY<sup>®</sup> - Browse Firmware Files

Figure 5-14 shows the chosen file ready for upgrade. Select “Upgrade” to begin the process.

## Firmware Upgrade

**Upgrade**

**Firmware Upgrade**

Name	Current Version	Progress
7890IXG	254	<div style="width: 0%;"> </div>

Firmware  7890IXG-V001-20160526-254.efp

Figure 5-14 : WebEASY<sup>®</sup> - Upgrade



**NOTE: The 7890IXG will restart upon upgrade completion.**

*This page left intentionally blank*

## 6. VLPRO REFERENCE CONTROLS

### 6.1. SYSTEM




Figure 6-1 : VistaLINK® - VLPro System Page

#### 6.1.1. Information

**Product Name:** This parameter displays the product name.

**Firmware Version:** This parameter displays the firmware version.

**Serial Number:** This parameter displays the serial number.

**Up Time:** This parameter returns the up time for the 7890IXG.

#### 6.1.2. License Control

**Product License File:** This control allows the user to select and upload a product license file

**Product Mac Address:** This parameter displays the card MAC address.

### 6.1.3. Configuration Management

**Import Configure File:** This control allows the user to select and upload a JSON configuration file to card.

**Export Configure File:** This control allows the user to save configuration data to a JSON file, and download the JSON file to a local host.


**Import Presets File:** This control allows the user to select and upload a preset file to the card.

**Export Presets File:** This control allows the user to save configuration data to a preset file, and download the preset file to a local host.

### 6.1.4. Control

**Card Reset:** This control allows the user to reboot the card.

## 6.2. IP INPUT



**Figure 6-2 : VistaLINK® - IP Input**

### 6.2.1. Access Port Control

**IP Address:** This parameter allows the user to set the IP Address for the data port.

**Netmask:** This parameter allows the user to set the netmask for the data port.

**Gateway:** This parameter allows the user to set the gateway for the data port.

### 6.2.2. Access Port Monitor

**Port Link Status:** This parameter returns the port link status: up or down.

**Port Link Speed:** This parameter returns the port link speed: down, spd10, spd100, spd1ge.

**Port RX SIDE Data Rate:** This parameter returns the port RX SIDE data rate.

**Port RX SIDE Good Frames:** This parameter returns the amount of good port RX SIDE frames.

**Port RX SIDE Error Frames:** This parameter returns the amount of error port RX SIDE frames.

**Port TX SIDE Data Rate:** This parameter returns the port TX SIDE data rate.

**Port TX SIDE Good Frames:** This parameter returns the amount of good port TX SIDE frames.

**Clear Stats:** This control allows the user to clear all stats.

## 6.3. INTERNET




Figure 6-3 : VistaLINK® - Internet

### **6.3.1. Internet Port Control**

**IP Address:** This parameter allows the user to set the IP Address for the control port.

**Netmask:** This parameter allows the user to set the netmask for the control port.

**Gateway:** This parameter allows the user to set the gateway for the control port.

**DHCP:** This control enables or disables DHCP.

**Speed Switch:** This control allows the user to change the switch speed.

### **6.3.2. Internet Port Monitor**

**Internet Link Status:** This parameter returns the internet link status: up or down.

**Internet Link Speed:** This parameter returns the internet link speed: down, spd10, spd100, spd1ge

**Internet RX SIDE Data Rate:** This parameter returns the internet RX SIDEdata rate.

**Internet RX SIDE Good Frames:** This parameter returns the amount of good internet RX SIDE frames.

**Internet RX SIDE Error Frames:** This parameter returns the amount of error internet RX SIDE frames.

**Internet TX SIDE Data Rate:** This parameter returns the internet TX SIDEdata rate.

**Internet TX SIDE Good Frames:** This parameter returns the amount of good internet TX SIDE frames.

**Clear Stats:** This control allows the user to clear all stats.

### **6.3.3. Buffer Control**

**Echo Port:** This parameter allows the user to select the echo port for the ARQ Qos Proxy.

**TX SIDE Buffers:** This parameter allows the user to select the TX SIDE Buffers for the ARQ Qos Proxy: k4, k8, k16, k32.

**RX SIDE Buffers:** This parameter allows the user to select the RX SIDE Buffers for the ARQ Qos Proxy: k4, k8, k16, k32.

## 6.4. INTERNET INPUT IP STREAM




Figure 6-4 : VistaLINK® - Internet Input IP Stream

### 6.4.1. Stream Control

**Stream Name:** This parameter displays the RX SIDEIP Stream profile name.

**Restart:** This control allows the user to restart the individual RX SIDEIP Stream.

### 6.4.2. Network

**ARQ Enable:** This parameter allows the user to select the RX SIDEIP Stream IP Transport Mode: ARQ or RTP. ARQ enables retransmissions so should normally be enabled when transmitting over the public internet or similar lower reliability networks.

**Destination IP Address:** This parameter allows the user to set the RX side IP Stream Network Destination IP address. This means the IP address that the received transport stream will be output on to the access port.

**Destination UDP Port:** This parameter allows the user to set the RX side IP Stream Network Destination port number. This means the IP address that the received transport stream will be output on to the access port.

**Source UDP Port:** This parameter allows the user to set the RX side IP Stream Network Source UDP port number. This means the UDP port that the received transport stream will be output on to the access port.

**Expected Jitter:** This parameter allows the user to set the IP Stream Network of RX side expected jitter for the WAN network.

## ARQ

**ARQ Port:** This parameter allows the user to set the RX side IP Stream ARQ port. This must match the ARQ port on the transmitting 7890IXG or Evertz Cloudbridge. By default, ARQ normally sends upstream retransmission request packets on UDP port 7020. The ARQ Port setting can be changed to any valid and non-conflicting UDP port. However, the same port number at both the encoder and the decoder should be defined. To help bypass firewall blocking, reset this to be the same port as the media UDP port, usually 10000.

**ARQ Mode:** This parameter allows the user to set the RX side IP Stream ARQ mode: Auto or Manual. Auto will attempt to pick appropriate values based on network conditions, while manual gives the user full control over retransmission parameters. When AUTO is set, you cannot set the number of retransmits or the round trip latency.

**Number Retransmits:** This parameter allows the user to set the RX side IP Stream ARQ Manual Mode maximum number of retransmissions when packet loss is detected. Higher values give more protection but increase the latency.

**Round Trip Latency:** This parameter allows the user to set the RX side IP Stream ARQ Manual Mode Round Trip Time, if it is known.

**Target Latency:** Target Latency, specifies the total delay, in milliseconds, allotted for the request, retransmission, and recovery process. The ARQ mechanism will attempt as many retries as possible within this target latency time. Thus, larger target latency times increase the delay before video is output, but allows for more chances of requesting and recovering any missing packets. The ARQ error correction operates through the addition of a small additional buffering delay to provide enough time to request and receive replacement for each lost packet. Target Latency gives the ARQ mechanism a target value for determining the necessary ARQ delay. The ARQ divides the Target Latency, specified in milliseconds, by the round-trip time to the video encoding source to determine the number of request attempts. Unless Robust Mode is enabled, it sets a minimum ARQ latency of one round-trip time. A larger Target Latency allows the system to increase the number of repeat requests.

**Max Burst Drop:** A Burst Drop delay can also be specified to delay any retransmission requests for a time equal to the maximum expected packet loss time, such as from dynamic router changes or other sources of burst loss.

**Multi-Retransmit Mode:** This parameter allows the user to enable or disable RX side Proxy ARQ Auto Mode Robust Mode. This gives high performance for stream recovery with the tradeoff of more latency. Normally, the ARQ will only require that a minimum of one repeat request is sent to the video encoding source device, regardless of the Target Latency. However, enabling Robust Mode will increase the minimum number of repeat requests to a minimum of two retries.

#### 6.4.3. Monitoring

**Name:** This parameter displays the RX side IP Stream Name.

**Running:** This parameter returns whether the RX side IP Stream is running or not: Yes or No.

#### 6.4.4. Network Status

**Sender IP:** This parameter returns the RX side IP Stream Network Sender IP. For example this could be the IP address of the sending 7890IXG-T.

**Port:** This parameter returns the RX side IP Stream Network port number.

**Bit Rate:** This parameter returns the RX side IP Stream Network bit rate.

**Packet Loss:** This parameter returns the RX side IP Stream Network packet loss.

**Jitter:** This parameter returns the RX side IP Stream Network jitter. Packets in incoming IP packet streams may lose their ordering or suffer variable delays during transport through an IP network. The proxy receiver buffers all incoming video/IP packets in a buffer and reorders RTP encapsulated packets by RTP sequence number. This parameter specifies the size of this incoming packet buffer in milliseconds of delay. Specify 0 here to disable this additional buffering when latency needs to be minimize.

**Dropped:** This parameter returns the RX side IP Stream Network drops.

**Total Packets:** This parameter returns the RX side IP Stream Network total packets.

#### 6.4.5. ARQ Status

**Unrecovered:** This parameter returns the number of RX side IP Stream ARQ unrecovered packets.

**Recovered:** This parameter returns the number of RX side IP Stream ARQ recovered packets.

**Max Burst Loss Packets:** This parameter returns the number of RX side IP Stream ARQ max burst loss packets.

**Port:** This parameter returns the RX side IP Stream ARQ port number.

## 6.5. INTERNET OUTPUT IP STREAM




Figure 6-5 : VistaLINK® - Internet Output IP Stream

### 6.5.1. Stream Control

**Profile Name:** This parameter allows the user to set the name for the IP stream profile.

**MultiCast Subscription Address:** This parameter allows the user to set The Multicast IP address of the target transport stream entering the IP access port.

**Source UDP Port:** This parameter allows the user to set the UDP port for the transport stream entering the IP access port.

**Destination IP Address:** This parameter allows the user to set the Unicast IP address for the destination device. This would be the Evertz cloud software address, or the address of the 7890IXG-R that you wish to target.

**Destination UDP Port:** This parameter allows the user to set the Destination UDP port for the destination device. This would be the Evertz cloud software address or the address of the 7890IXG-R that you wish to target.

**ARQ Port:** This parameter allows the user to set ARQ port for retransmission requests over the internet.  
**NOTE:** Failure to set this and allow it through any firewalls will prevent any retransmission requests, giving little to no protection for your stream. Make sure this value is different than any UDP port for video data.

**Restart:** This control allows the user to restart the individual TX side Proxy.

#### 6.5.2. Stream Status

**Name:** This parameter returns the name of the individual IP stream.

**Running:** This parameter returns whether the IP stream is running or not: Yes or No.

#### 6.5.3. Receive Status

**Port:** This parameter returns the IP Stream Receive port number.

**Bit Rate:** This parameter returns the IP Stream Received bit rate.

**Packet Loss:** This parameter returns the IP Stream Received packet loss.

**Total Packets:** This parameter returns the IP Stream Received total packets.

#### 6.5.4. Transmit Status

**UDP Port:** This parameter returns the IP Stream Transmit UDP port.

**ARQ Port:** This parameter returns the IP Stream Transmit ARQ Port.

**Bit Rate:** This parameter returns the IP Stream Transmit Bit rate.

**Total Packets:** This parameter returns the total number of IP Stream packets transmit.

**Receivers:** This parameter returns the IP Stream Transmit Receivers.

### 6.6. SERVER




Figure 6-6 : VistaLINK® - Server

#### 6.6.1. Server

**Use Server:** This parameter allows the user to enable or disable RX side Proxy Server Mode.

**IP Address or Hostname:** This parameter returns the RX side Proxy Server Mode IP address or hostname.

**Echo Port:** This parameter returns the RX side Proxy Server Mode Echo port number. NOTE: Please make sure this is different than ARQ and UDP data port numbers and that it can pass through any firewalls on the network.

## 6.7. NOTIFY




Figure 6-7 : VistaLINK® - Notify

### 6.7.1. Output Notify

**Output Trap:** This control allows the user to enable or disable trap reporting.

**Output Faults:** This parameter returns the present state of a particular fault. The values for this object are false and true.

### 6.7.2. Input Notify

**Input Trap:** This control allows the user to enable or disable trap reporting.

**Input Faults:** This parameter returns the present state of a particular fault. The values for this object are false and true.

## 6.8. TRAPS

Description	Error
Output Proxy	Not present
Output Proxy Bandwidth	Over Limit
Input	Not present
Input Bandwidth	Over Limit

## 6.9. TOP MENU BAR

### 6.9.1. Refresh




Figure 6-8 : VistaLINK® - VLPro Header\Refresh

Refresh tab is used to refresh the page. By clicking on Refresh, It allows any changes made by the user to the card to reflect on the VLPro.

### 6.9.2. Auto Refresh




Figure 6-9 : VistaLINK® - VLPro Header\Auto refresh

Auto Refresh is used to refresh page continuously. The page keeps refreshing once the user click on auto refresh. To stop from refreshing click again on auto refresh.

### 6.9.3. Apply




Figure 6-10 : VistaLINK® - VLPro Header\Apply

Apply tab is used to implement any change through VLPro. By clicking on apply, it allows to implement any change to the card through VLPro.

### 6.9.4. Dynamic Apply




Figure 6-11 : VistaLINK® - VLPro Header\Dynamic Apply

Dynamic apply is used to implement changes automatically. This feature allows the user to automatically apply any change to the card through webpage

## 6.10. UPGRADE

To Upgrade TX SIDE or RX SIDE follow the steps:

- 1) Right click on the IP address of the card that the user wants to upgrade and then click version information.
- 2) Version information will open and then click on 7890IXG card.




Figure 6-12 : VistaLINK® - Select Hardware




Figure 6-13 : VistaLINK® - Upgrade Card

*This page left intentionally blank*

## 7. CARD EDGE

### 7.1. MODULE STATUS LEDS

Two large LEDs on the front of the main board indicate the general health of the module:

**Local Fault:** This red led indicate poor module health or if a local input power fault exists( i.e.: a blown fuse). The local fault indication can also be reported to the frame through the frame status jumper.


**Module OK:** This green led indicates good module health. It will be on when the board is good.

### 7.2. SERIAL PORT

This port j4 is used to communicate with the board. It allows the user to do initial set up of the card through ribbon cable. To do initial set up through this port follow **set up** (procedure #3) in startup guide.

### 7.3. USB PORT

This port is used for the same purpose as serial port.



**Figure 7-1 : Card Front View**

## 8. FEC

The Forward Error Correction allows the card to automatically recover lost packets. This increases the productivity of the card by transporting data with better quality. Once the card is upgraded to the FEC supported firmware, follow these steps to confirm if all configuration settings match the requirements to enable FEC:

- 1) Make sure these port values match on the TX and RX side WebPages; these can also be monitored and controlled through VLPro. The Destination IP address should not be entered more than one. To enable FEC the user must start three different TX side Proxies. For three different TX side Proxies to receive the stream, the user may need the source to multicast its stream.

The screenshot shows the 'Internet Output IP Stream' configuration page. The left sidebar has a 'Stream Control' section with four rows of data for Output IP Streams 1 through 4. Each row includes fields for Profile Name, MultiCast Subscription Address, Source UDP Port, Destination IP Address, Destination UDP Port, ARQ Port, and a 'Restart' button. The 'Profile Name' column contains 'TX\_proxy1' through 'TX\_proxy4'. The 'MultiCast Subscription Address' column contains '239.0.0.63', '227.0.0.1', '239.0.0.123', and '138.0.0.1'. The 'Source UDP Port' column contains '1,234', '1,235', '1,236', and '1,237'. The 'Destination IP Address' column contains '192.168.100.1', '192.168.100.1', '192.168.100.1', and '192.168.255.1'. The 'Destination UDP Port' column contains '20,000' (red), '7,020' (orange), '50,000' (green), and '10,000' (blue). The 'ARQ Port' column contains '20,000' (red), '7,020' (orange), '50,000' (green), and '10,000' (blue). The 'Restart' column contains 'Restart' buttons for each row. The 'FEC' section below the table is currently empty.

	Profile Name	MultiCast Subscription Address	Source UDP Port (0 to 65535)	Destination IP Address	Destination UDP Port (0 to 65535)	ARQ Port (0 to 65535)	Restart
Output IP Stream 1	TX_proxy1	239.0.0.63	1,234	192.168.100.1	20,000	20,000	<input type="button" value="Restart"/>
Output IP Stream 2	TX_proxy2	227.0.0.1	1,235	192.168.100.1	7,020	7,020	<input type="button" value="Restart"/>
Output IP Stream 3	TX_proxy3	239.0.0.123	1,236	192.168.100.1	50,000	50,000	<input type="button" value="Restart"/>
Output IP Stream 4	TX_proxy4	138.0.0.1	1,237	192.168.255.1	10,000	10,000	<input type="button" value="Restart"/>

Figure 8-1 : WebEASY® - TX Side

All the source UDP ports on different streams on both TX and RX sides should be different and should match the destination UDP port on the other side. The ARQ port should be set equal to the source UDP port on the RX side.

**Stream Control**

Input IP Stream	Stream Name	Restart
Input IP Stream 1	RX_proxy1	<b>Restart</b>
Input IP Stream 2	RX_proxy2	<b>Restart</b>
Input IP Stream 3	RX_proxy3	<b>Restart</b>
Input IP Stream 4	RX_proxy4	<b>Restart</b>

**Network**

Input IP Stream	ARQ Enable	Destination IP Address	Destination UDP Port (0 to 65535)	Source UDP Port (0 to 65535)	Expected Jitter (0 to 65535)
Input IP Stream 1	ARQ ▾	239.0.0.63	1,234	20,000	50
Input IP Stream 2	ARQ ▾	192.168.255.1	1,235	7,020	50
Input IP Stream 3	ARQ ▾	192.168.255.1	1,236	50,000	50
Input IP Stream 4	ARQ ▾	192.168.255.1	1,237	10,000	50

**ARQ**

Input IP Stream	ARQ Port (0 to 65535)	ARQ Mode	Number Retransmits (0 to 65535)	Round Trip Latency (0 to 65535)	Target Latency (0 to 65535) ms	Max Burst Drop (0 to 2147483647)	Multi-Retransmit Mode
Input IP Stream 1	20,000	Auto ▾			750	40	Enable ▾
Input IP Stream 2	7,020	Auto ▾			750	40	Enable ▾
Input IP Stream 3	50,000	Auto ▾			750	40	Enable ▾
Input IP Stream 4	10,000	Auto ▾			750	40	Enable ▾

Figure 8-2 : WebEASY® - RX Side

- 2) Under the FEC tab the following parameters should match on the TX and RX sides and should have large gaps between the different FEC ports (ex. Keep a gap of 1000 to prevent from toggling between the streams). FEC row and column parameters should always be equal to 10.

FEC			
	Row (0 to 65535)	Column (0 to 65535)	FEC Port (0 to 65535)
Output IP Stream 1	10	10	10,002
Output IP Stream 2	10	10	12,002
Output IP Stream 3	10	10	14,002
Output IP Stream 4	10	10	16,002

Figure 8-3 : WebEASY® - TX Side

FEC	
	FEC Port (0 to 65535)
Input IP Stream 1	10,002
Input IP Stream 2	12,002
Input IP Stream 3	14,002
Input IP Stream 4	16,002

Figure 8-4 : WebEASY® - RX Side

*This page left intentionally blank*